QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233
Unit 9 / 376 Newbridge Road, Moorebank NSW 2170
Web site: www.qnnsafe.com.au
Email: info@qnnsafe.com.au
Phone: 02-87982669

QNN® Safe USER'S MANUAL FOR MC

CREDIT CARD SAFE SERIES

Serial Number:

This package contents:

- User manual
- 1 External Battery Box
- 4 Bolt Down Screws
- 4 AA Batteries
- 2 Emergency backup Keys

Please contact your retailer or Qnn Safe Australia P/L if any shortage occurred
For the first time use, it needs the external battery power support:

- Insert the supplied 4 AA batteries into the External Battery Box
- Connect the power to the front panel. The power inlet is located on the bottom side of the Key Pad panel.
  After the safe is opened, please replace the batteries into the internal battery box, which is located behind the door plate
- Safe can be opened by swiping the registered MAGNETIC STRIPPED CARD (Ex. Personal ID cards or most major credit cards)
- Or by entering personal digital code.
- After swipe the Card or after enter the right code, Safe is now unlocked.

The factory setting for the digital code is: "1 2 3 4 5 6"

Opening instructions:

- Using PERSONAL CODE:
  - Input 4-6 digits PERSONAL CODE, (Factory setting: 123456)
  - "OPENED" displayed with 2 beeps, then the safe is unlocked
  - E-CODE Displayed with 3 beeps means it is a wrong code try. 3 continual wrong code tries will be held for 15 minutes.

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233
Unit 9 / 376 Newbridge Road, Moorebank NSW 2170
Web site: www.qnnsafe.com.au
Email: info@qnnsafe.com.au
Phone: 02-87982669

- **After the Holding is activated, there is no way to de-activate the Holding within the 15 minutes period.** HOLD** **then displayed to indicate the remaining holding time in minutes**

- Using MAGNETIC STRIPPED CARD:
  - Press A, then swipe the card from right to lift (Please face the magnetic strip down)
  - "OPENED" displayed with 2 beeps, then the safe is unlocked

Closing instructions:

You need to enter your PERSONAL CODE, or swipe your Card to lock the safe. This code or card will be the keys for next opening.

- Using PERSONAL CODE:
  - Close the door
  - Input 4-6 digits PERSONAL CODE (Could be the old code or a new code)
  - "CLOSED" displayed with 2 beeps, then the safe is locked
- Using MAGNETIC STRIPPED CARD:
  - Close the door
  - Press A, then swipe the card from right to lift (Please face the magnetic strip down)
  - "CLOSED" displayed with 2 beeps, then the safe is locked

Emergency Backup

In an emergency saturation, safe can be opened by the Emergency key. (Override the digital lock). To expose the key hole you need to screw off the little metal button on the door front Then turn the master key counter clockwise to unlock the safe.
You need to reset a new code after open the safe using **Emergency Key**

To reset the code:

- Keep the Emergency key at counter clockwise position
- Input 4-6 digits new PERSONAL CODE
- Press A, "CLOSED" then displayed with 2 beeps and then LO-BAT displayed. which indicate that the new code is set successful
- Close and lock the door by removing the Emergency Key
- Using the New Code to unlock the safe, and remember the New Code

Cautions:

- **Do not store the Emergency Keys and the External Battery Box inside the safe**
- **When the "LO-BAY" display with 3 beeps, it means that the batteries need to be replaced. Please replace new batteries as soon as possible.**